

Emissions Control System

GENERAL

CRANKCASE EMISSION CONTROL SYSTEM

POSITIVE CRANKCASE VENTILATION (PCV) VALVE

EVAPORATIVE EMISSION CONTROL SYSTEM

EVAPORATIVE (EVAP) CANISTER
CANISTER AIR FILTER
EVAPORATIVE (EVAP) CANISTER PURGE SOLENOID VALVE
FUEL FILLER CAP
OVERFILL LIMITER (TWO WAY VALVE)

EXHAUST EMISSION CONTROL SYSTEM

GENERAL

HAMID REZAI...ALYANCE...TEL:09375572121...telegram channel:@alyance1

SPECIFICATIONS

EA4C2583

Item	Specification	
Purge Control Solenoid Valve (PCSV)	Type	Duty Control type
	Resistance (Ω)	19 ~ 22 at 20 °C (68 °F)

TIGHTENING TORQUE

Item	N·m	kg·cm	lb·ft
Positive Crankcase Ventilation Valve	8 ~ 12	80 ~ 120	6 ~ 8

TROUBLESHOOTING

Symptom	Suspect area	Remedy
Engine will not start or hard to start	Vacuum hose disconnected or damaged	Repair or replace
	Malfunction of the EVAP. Canister Purge Solenoid Valve	Repair or replace
Rough idle or engine stalls	Vacuum hose disconnected or damaged	Repair or replace
	Malfunction of the PCV valve	Replace
	Malfunction of the evaporative emission canister purge system	Check the system; if there is a problem, check related components parts
Excessive oil consumption	Positive crankcase ventilation line clogged	Check positive crankcase ventilation system

COMPONENTS

Components	Function	Remarks
Crankcase Emission System Positive Crankcase Ventilation (PCV) valve	HC reduction	Variable flow rate type
Evaporative Emission System Evaporative emission canister Purge Control Solenoid Valve (PCSV)	HC reduction HC reduction	Duty control solenoid valve
Exhaust Emission System MFI system (air-fuel mixture control device) Three-way catalytic converter	CO, HC, NOx reduction CO, HC, NOx reduction	Heated oxygen sensor feedback type Monolithic type


MFI : Multiport Fuel Injection

EVAP : Evaporative Emission

COMPONENTS LOCATION

E5A329D7

HAMID REZAI...ALYANCE...TEL:09375572121...telegram channel:@alyance1









- | | |
|--|------------------------|
| 1. Purge Control Solenoid Valve (PCSV) | 3. Canister |
| 2. PCV Valve | 4. Catalytic Converter |
| 5. Two Way Valve & Cut Valve | 6. Canister Filter |

EERF301A

HAMID REZAI...ALYANCE...TEL:09375572121...telegram channel:@alyance1

EC -4


EMISSIONS CONTROL SYSTEM

1	Purge Control Solenoid Valve (PCSV)	2	Positive Crankcase Ventilation (PCV) Valve
 KERE020A		 KERE083A	
3	Canister	4	Catalytic Converter
 KERE040B		 KERE087A	
5	Two way & Cut Valve	6	Canister Filter
 Fuel Tank Two Way & Cut Valve ERFE026A		 Rear Left wheel house Canister Filter EERF041B	

CRANKCASE EMISSION
CONTROL SYSTEM

HAMID REZAI...ALYANCE...TEL:09375572121...telegram channel:@alyance1

COMPONENTS LOCATION ED593335



HAMID REZAI...ALYANCE...TEL:09375572121...telegram channel:@alyance1





- During Low Load Operation
- During High Load Operation
- Fresh Air

CRANKCASE EMISSION CONTROL SYSTEM

EC -7

POSITIVE CRANKCASE VENTILATION (PCV) VALVE

OPERATION E7AEA1F5

Intake manifold side (No vacuum)  Rocker cover side BEGE001S		Intake manifold side (High vacuum)  Rocker cover side BEGE001T	
Engine condition	Not running	Engine condition	Idling or decelerating
PCV valve	Not operating	PCV valve	Fully operating
Vacuum passage	Restricted	Vacuum passage	Small
Intake manifold side (Moderate vacuum)  Rocker cover side BEGE001U		Intake manifold side (Low vacuum)  Rocker cover side BEGE001V	
Engine condition	Normal operation	Engine condition	Accelerating and high load
PCV valve	Properly operating	PCV valve	Slightly operating
Vacuum passage	Large	Vacuum passage	Very large

EC -8

EMISSIONS CONTROL SYSTEM

REMOVAL


EEC0EB80

1. Disconnect the ventilation hose from the positive crankcase ventilation (PCV) valve. Remove the PCV valve from the rocker cover and reconnect it to the ventilation hose.
2. Run the engine at idle and put a finger on the open end of the PCV valve and make sure that intake manifold vacuum can be felt.



NOTE

The plunger inside the PCV valve will move back and forth.




KERE083A

INSPECTION

E28F9F53

1. Remove the PCV valve.
2. Insert a thin stick(A) into the PCV valve(B) from the threaded side to check that the plunger moves.
3. If the plunger does not move, the PCV valve is clogged. Clean it or replace.




EGQE603J

INSTALLATION

E20AEB A6

Install the PCV valve and tighten to the specified torque.

PCV valve : 0.8~1.2 kgf·m

EVAPORATIVE EMISSION CONTROL SYSTEM**EC -9****EVAPORATIVE EMISSION CONTROL SYSTEM****COMPONENTS** E988A4E0

EERF0011

CANISTER

Canister accumulates vapor from fuel tank. ECM controls PCSV to send vapor to intake manifold.

PURGE CONTROL SOLENOID VALVE (PCSV)

PCSV is installed between intake manifold and canister. ECM controls PCSV, which is operated by vacuum, to send vapor in canister to intake manifold.

EC -10**EMISSIONS CONTROL SYSTEM****INSPECTION** ECB4B8

1. Disconnect the vacuum hose from the throttle body, and connect a vacuum pump to the vacuum hose.
2. Check the following points when the engine is cold [engine coolant temperature 60°C(140°F) or below] and when it is warm [engine coolant temperature 80°C(176°F) or higher].

WHEN ENGINE IS COLD

Engine operating condition	Applied vacuum	Result
Idling	50 kPa (7.3 psi)	Vacuum is held
3,000 rpm		

WHEN ENGINE IS WARM

Engine operating condition	Applied vacuum	Result
Idling	50 kPa (7.3 psi)	Vacuum is held
Within 3 minutes after engine start at 3,000 rpm	Try to apply vacuum	Vacuum is released
After 3 minutes have passed after engine start at 3,000 rpm	50 kPa (7.3 psi)	Vacuum will be held momentarily, after which, it will be released

EVAPORATIVE EMISSION CONTROL SYSTEM

EC -11

EVAPORATIVE (EVAP) CANISTER


INSTALLATION E6ECCF12

Installation is in reverse order of removal.

REMOVAL EA9C2B0C

1. Disconnect hoses (A), (B) connecting to the canister(D).
2. Unfasten two mounting bolts(C) and remove the canister(D).


Torque : 4.0 ~ 5.5kgf·m



EERF040A

INSPECTION EAFCFAC

1. Look for loose connections, sharp bends or damage to the fuel vapor lines.
2. Look for distortion, cracks or fuel damage.
3. After removing the canister, inspect for cracks or damage.




KERE039A

CANISTER AIR FILTER

REPLACE E4F42BA3

1. Remove the rear left wheel house.
(Refer to "BD" group)
2. Unfasten three mounting nuts.



KERE041A

3. Remove the canister air filter(A).
4. Install a new canister air filter.

EVAPORATIVE EMISSION CONTROL SYSTEM**EC -13****EVAPORATIVE (EVAP) CANISTER
PURGE SOLENOID VALVE****INSPECTION**

E69C9BA7

**NOTE**


When disconnecting the vacuum hose, make an identification mark on it so that it can be reconnected to its original position.

1. Disconnect the vacuum hose from the solenoid valve.
2. Detach the harness connector.
3. Connect a vacuum pump to the nipple to which the red-striped vacuum hose was connected.
4. Apply vacuum and check when voltage is applied to the PCSV and when the voltage is discontinued.


Battery voltage	Normal condition
When applied	Vacuum is released
When discontinued	Vacuum is maintained

5. Measure the resistance between the terminals of the solenoid valve.

PCSV coil resistance(Ω) :
19 ~ 22 Ω at 20 (68)



KERE001M



KERE001L

EC -14


EMISSIONS CONTROL SYSTEM

FUEL FILLER CAP

DESCRIPTION E6E243DC

A ratchet tightening device on the threaded fuel filler cap reduces the chances of incorrect installation, which would


seal the fuel filler. After the gasket on the fuel filler cap and the filler neck flange contact each other, the ratchet produces a loud clicking noise indicating the seal has been set.




EVAPORATIVE EMISSION CONTROL SYSTEM**EC -15****OVERFILL LIMITER (TWO WAY VALVE)****CHARACTERISTICS OPERATION () - VACUUM VALVE****DESCRIPTION** EDB003C4

Two-way valve consists of a pressure valve and a vacuum valve. The pressure valve opens when the internal pressure of fuel tank gets higher than specification and the vacuum valve opens when the fuel tank forms a vacuum.

Pressure (kPa)	Flow
-0.981 kPa	above 5ℓ /min



EERF014A



EERF080A

CHARACTERISTICS OPERATION () - PRESSURE VALVE

Pressure (kPa)	Flow
3.432 kPa	below 3ℓ /min
4.903 kPa	above 10ℓ /min
5.884 kPa	above 15ℓ /min
9.806 kPa	above 25ℓ /min

EXHAUST EMISSION CONTROL SYSTEM

DESCRIPTION E933DCFA

Exhaust emissions (CO, HC, NOx) are controlled by a combination of engine modifications and the addition of special control components.

Modifications to the combustion chamber, intake manifold, camshaft and ignition system form the basic control system.

These items have been integrated into a highly effective system which controls exhaust emissions while maintaining good driveability and fuel economy.

AIR/FUEL MIXTURE CONTROL SYSTEM [MULTIPOINT FUEL INJECTION (MFI) SYSTEM]

The MFI system is a system which uses the signals from the heated oxygen sensor to activate and control the injector installed in the manifold for each cylinder, thus precisely regulating the air/fuel mixture ratio and reducing emissions.

This in turn allows the engine to produce exhaust gases of the proper composition to permit the use of a three way catalyst. The three way catalyst is designed to convert the three pollutants (1) hydrocarbons (HC), (2) carbon monoxide (CO), and (3) oxides of nitrogen (NOx) into harmless substances. There are two operating modes in the MFI system.

1. Open Loop air/fuel ratio is controlled by information programmed into the ECM.
2. Closed Loop air/fuel ratio is adjusted by the ECM based on information supplied by the oxygen sensor.