


vehicle : 301		VIN: VF3DDNFPTGJ721797 / OPR : 14466	
domain	driver information	function	Direction indicators left on alert
component			

principle




D3CZHJ5R

item code	description	information
0004	null	/ instrument panel
6202	null	driver's side front door lock assembly
BB00	null	ancillaries battery
BFRM	null	engine fuse and relay box
BSI1	null	built-in systems interface
CA00	null	ignition switch
CV00	null	control under the steering wheel
E934	null	crimp one information (or equipotential 934) wire
E935	null	crimp one information (or equipotential 935) wire
E938	null	crimp one information (or equipotential 938) wire
E939	null	crimp one information (or equipotential 939) wire
EM35B	null	crimp earth (earth point number 35B)
EM37A	null	crimp earth (earth point number 37A)
MC13	null	body earth point number 13
MC35	null	body earth point number 35
MC37A	null	body earth point number 37A
MM01	null	engine earth point number 01

vehicle : 301	VIN: VF3DDNFPTGJ721797 / OPR : 14466		
domain	driver information	function	Direction indicators left on alert
component			

wiring



D3CZHJ5G

item code	description	information
0004	null	/ instrument panel
6202	null	driver's side front door lock assembly
BB00	null	ancillaries battery
BFRM	null	engine fuse and relay box
BSI1	null	built-in systems interface
CA00	null	ignition switch
CV00	null	control under the steering wheel
E934	null	crimp one information (or equipotential 934) wire
E935	null	crimp one information (or equipotential 935) wire
E938	null	crimp one information (or equipotential 938) wire
E939	null	crimp one information (or equipotential 939) wire
EM35B	null	crimp earth (earth point number 35B)
EM37A	null	crimp earth (earth point number 37A)
MC13	null	body earth point number 13
MC35	null	body earth point number 35
MC37A	null	body earth point number 37A
MM01	null	engine earth point number 01