


[illegible]

item code	description	information
0004	null	/ instrument panel
6416	null	right-hand exterior mirror
BB00	null	ancillaries battery
BFRM	null	engine fuse and relay box
BSI1	null	built-in systems interface
CA00	null	ignition switch
CV00	null	control under the steering wheel
E934	null	crimp one information (or equipotential 934) wire
E935	null	crimp one information (or equipotential 935) wire
E938	null	crimp one information (or equipotential 938) wire
E939	null	crimp one information (or equipotential 939) wire
EM35B	null	crimp earth (earth point number 35B)
MC13	null	body earth point number 13
MC35	null	body earth point number 35
MM01	null	engine earth point number 01

@alyance,

vehicle : 301	VIN: VF3DDNFPTGJ721797 / OPR : 14466		
domain	driver information	function	exterior temperature information
component			

wiring



D3CZHJEG

item code	description	information
0004	null	/ instrument panel
6416	null	right-hand exterior mirror
BB00	null	ancillaries battery
BFRM	null	engine fuse and relay box
BSI1	null	built-in systems interface
CA00	null	ignition switch
CV00	null	control under the steering wheel
E934	null	crimp one information (or equipotential 934) wire
E935	null	crimp one information (or equipotential 935) wire
E938	null	crimp one information (or equipotential 938) wire
E939	null	crimp one information (or equipotential 939) wire
EM35B	null	crimp earth (earth point number 35B)
MC13	null	body earth point number 13
MC35	null	body earth point number 35
MM01	null	engine earth point number 01

@alyance,