

ALYANCE:HAMID REZAI:TEL:۰۹۳۷۵۵۷۲۱۲۱

item code	description	information
0004	null	/ instrument panel
8404	null	aerial
8410	null	/ audio system
8422	null	Front LH speaker
8423	null	Front RH speaker
8430	null	rear left speaker
8435	null	rear right speaker
8482	null	audio-navigation microphone / audio-telephone microphone
8499	null	external audio input block
84A1	null	USB socket on front centre console
BB00	null	ancillaries battery
BFRM	null	engine fuse and relay box
BSI1	null	built-in systems interface
CA00	null	ignition switch
CV00	null	control under the steering wheel
E934	null	crimp one information (or equipotential 934) wire
E935	null	crimp one information (or equipotential 935) wire
E938	null	crimp one information (or equipotential 938) wire
E939	null	crimp one information (or equipotential 939) wire
EM35B	null	crimp earth (earth point number 35B)
MC13	null	body earth point number 13
MC35	null	body earth point number 35
MC50A	null	body earth point number 50
MM01	null	engine earth point number 01