


vehicle : 301		VIN: VF3DDNFPTGJ721797 / OPR : 14466	
domain	driving assistance	function	cruise control/speed limiter
component			


principle



item code	description	information
0004	null	/ instrument panel
1261	null	accelerator pedal position sensor /
1320	null	engine ECU /
2120	null	dual function brake switch /
7306	null	cruise control safety switch (clutch)
7800	null	calculateur controle de stabilite
BB00	null	ancillaries battery
BFRM	null	engine fuse and relay box
BSI1	null	built-in systems interface
CA00	null	ignition switch
CV00	null	control under the steering wheel
E900A	null	crimp one information (or equipotential 276A) wire
E900B	null	crimp one information (or equipotential 900B) wire
E901A	null	crimp one information (or equipotential 901A) wire
E901B	null	crimp one information (or equipotential 901B) wire
E934	null	crimp one information (or equipotential 934) wire
E935	null	crimp one information (or equipotential 935) wire
E938	null	crimp one information (or equipotential 938) wire
E939	null	crimp one information (or equipotential 939) wire
EC03A	null	splice of an "ignition +" protected by fuse no. 03A
EM35B	null	crimp earth (earth point number 35B)
MC35	null	body earth point number 35
MM01	null	engine earth point number 01

vehicle : 301	VIN: VF3DDNFPTGJ721797 / OPR : 14466		
domain	driving assistance	function	cruise control/speed limiter
component			

wiring



D3CZDJ2G

item code	description	information
0004	null	/ instrument panel
1261	null	accelerator pedal position sensor /
1320	null	engine ECU /
2120	null	dual function brake switch /
7306	null	cruise control safety switch (clutch)
7800	null	calculateur controle de stabilite
BB00	null	ancillaries battery
BFRM	null	engine fuse and relay box
BSI1	null	built-in systems interface
CA00	null	ignition switch
CV00	null	control under the steering wheel
E900A	null	crimp one information (or equipotential 276A) wire
E900B	null	crimp one information (or equipotential 900B) wire
E901A	null	crimp one information (or equipotential 901A) wire
E901B	null	crimp one information (or equipotential 901B) wire
E934	null	crimp one information (or equipotential 934) wire
E935	null	crimp one information (or equipotential 935) wire
E938	null	crimp one information (or equipotential 938) wire
E939	null	crimp one information (or equipotential 939) wire
EC03A	null	splice of an "ignition +" protected by fuse no. 03A
EM35B	null	crimp earth (earth point number 35B)
MC35	null	body earth point number 35
MM01	null	engine earth point number 01